

# MIMOSA CRIS v2.1

## Measurement Setup Tables

TRANSDUCER #54

TR_ASSET_SITE
TR_ASSET_ID
TR_DB_SITE
TR_DB_ID
TR_TYPE_CODE
OUT_EU_DB_SITE
OUT_EU_DB_ID
OUT_EU_TYPE_CODE
OUT_AMPLITUDE
PER_EU_DB_SITE
PER_EU_DB_ID
PER_EU_TYPE_CODE
GMT_LAST_CALIB
SELF_POWERED_YN
NAME
GMT_LAST_UPDATED
LAST_UPD_DB_SITE
LAST_UPD_DB_ID
RSTAT_TYPE_CODE

DATA\_SOURCE #52

DS_ASSET_SITE
DS_ASSET_ID
DS_DB_SITE
DS_DB_ID
DS_TYPE_CODE
NAME
LAST_UPD_DB_SITE
LAST_UPD_DB_ID
RSTAT_TYPE_CODE

MEAS\_LOCATION #47

MEAS_LOC_SITE
MEAS_LOC_ID
ML_DB_SITE
ML_DB_ID
ML_TYPE_CODE
SEGMENT_OR_ASSET
SEGMENT_SITE
SEGMENT_ID
ASSET_ORG_SITE
ASSET_ID
DS_DB_SITE
DS_DB_ID
DS_TYPE_CODE
TR_DB_SITE
TR_DB_ID
TR_TYPE_CODE
TA_ORIENT_DEG
TA_DB_SITE
TA_DB_ID
TA_TYPE_CODE
MIM_LOC_SEQ
MOTION_DIRECTION
MIM_USER_PREFIX
MC_DB_SITE
MC_DB_ID
MC_TYPE_CODE
MC_CALC_SIZE
UPDATE_INTERVAL
INT_EU_DB_SITE
INT_EU_DB_ID
INT_EU_TYPE_CODE
COLLECT_DURATION
DUR_EU_DB_SITE
DUR_EU_DB_ID
DUR_EU_TYPE_CODE
USER_TAG_IDENT
BARCODE
NAME
GMT_LAST_UPDATED
LAST_UPD_DB_SITE
LAST_UPD_DB_ID
RSTAT_TYPE_CODE